BURG WÄCHTER

Universal Safe
Catalogue No. U 2 E

OPERATING INSTRUCTIONS



Universal Safe - U2E

OPERATING INSTRUCTIONS FOR SAFE & ELECTRONIC CONTROL PANEL

IMPORTANT:

- Please keep your keys in a secure place, but **not** in the safe.
- Keep your personal code secure.
- Do not use personal data (eg: birthdays, telephone numbers etc).

HOW TO OPEN THE SAFE WITH THE KEY:

- Remove the cap that is located between the knob & keypad on the front of the safe.
- Insert the key & turn it anti-clockwise. Then turn the knob clockwise & open the door.

HOW TO INSTALL THE BATTERIES:

- Remove the plastic cover from the box located on the inside of the safe door. Insert 4 x AA batteries, 1.5v (Alkaline).

HOW TO PROGRAM YOUR PERSONAL CODE:

- Open the door
- Press and release the **RED** button on the inner side of the door jamb and the **GREEN** control light on the front of the safe will light up.
- Enter your personal code. (3 - 6 digits).
- Press the ENTER key to store your new code.

HOW TO OPEN THE SAFE USING THE KEYPAD:

- Press the ENTER key.
- Enter your personal code.
- Press the ENTER key.
- After the melody you can open the door with the knob (turning clockwise).

HOW TO CLOSE THE SAFE:

- Close the door & turn the knob anti-clockwise.

BATTERY INDICATOR:

- The batteries should be replaced immediately if the **RED** light comes on.
- After having replaced the batteries the personal code must be re-programmed.

ALARM IN CASE OF WRONG CODE:

- After the third incorrect code the opening mechanism is blocked for 2 minutes.
- After this time has elapsed the safe can be opened with the correct code.

INSTALLATION:

- The safe can be installed by securing to a wall or the floor with the masonry bolts provided.